



# TOURATECH

TOURING RALLYE RACING TECHNOLOGY

09-040-0280-1

## Installation Instructions Head Light Cover BMW R1100GS

### Contains:

- 1 x Clear Polycarbonate Head Light Guard
- 1 x Spacer 45 mm
- 2 x Spacer 24 mm
- 1 x Screw dome head M5x70
- 2 x Screw dome head M5x60
- 3 x Washer M5



### Installation of the head light cover:

Remove the original Phillips screws around the head light retaining cover.  
Careful not to let the head light fall out!

Now set the 45mm spacer in the upper middle bore of the head light retaining cover and the two 24mm spacers in the lower (outer) bores.

Remove the protective cover of the head light cover.

Attach the head light cover with the supplied dome head screws M5x60, M5x70 and the washers M5. Se the washers between the screw head and the head light cover.



### NOTE:

**This head light cover does not have German TUV approval and is therefore not street legal in Germany.**