

Installation Instruction: Sport Windscreen with Spoiler R1200GS

Contains:

- 1 x Windscreen Sport R1200GS with holes for spoiler
- 1 x Spoiler for windscreen
- 2 x Attachment part plastic for Spoiler
- 4 x Screw dome head M5x12
- 4 x Washer plastic

Attention: important tips, explanations

Information for windscreen adjustment can be found in BMW manual.

Installation Windscreen

Remove the original R1200GS windscreen. Windscreen is attached with two screws up front and one on each side at the windscreen angle adjusters. Cap nuts on the inside of the fairing need to be removed in order to remove the adjustments and hardware.

Use the adjustment hardware with the new Sport windscreen. Disassemble the adjustment assembly carefully using small screwdriver. Careful not to break the plastic teeth. These plastic parts are marked with "L" Left and "R" Right.

Install them in reverse order on the Sport windscreen.

Installation Spoiler

Attach the spoiler using plastic attachment parts and hardware as shown on photo 1 and 2 (left & right), each side with following hardware:

- A) 2 x Screw dome head M5x12
- B) 4 x Washer plastic
- C) 1 x Plastic attachment part

NOTE: Do not tighten the screws too tight! Plastic parts may crack if over tightened.

Plastic attachment parts are used for height adjustment. Turn plastic attachment parts down for lower spoiler position and up for high spoiler position.